



X1-Hybrid-LV

3.0 KW / 3.7 KW / 4.0 KW / 4.6 KW/ 5.0 KW / 6.0 KW

User Manual

Version 1.0



www.solaxpower.com

STATEMENT

Copyright

Copyright © SolaX Power Technology (Zhejiang) Co., Ltd. All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means without the prior written permission of SolaX Power Technology (Zhejiang) Co., Ltd.

Trademarks

source and other symbol or design (brand name, logo) that distinguishes the products or services offered by SolaX has been trademark protected. Any unauthorized use of the above stated trademark may infringe the trademark right.

Notice

Please note that certain products, features, and services mentioned in this document may not be within the scope of your purchase or usage. Unless otherwise specified in the contract, the contents, information, and recommendations presented in this document are provided "as is" by SolaX. We do not provide any warranties, guarantees, or representations, whether express or implied.

The content of the documents is reviewed and updated as needed. However, occasional discrepancies may occur. SolaX retains the right to make improvements or changes in the product(s) and the program(s) described in this manual at any time without prior notice.

The images included in this document are solely for illustrative purposes and may differ based on the specific product models.

For more detailed information, kindly visit the website of SolaX Power Technology (Zhejiang) Co., Ltd. at www.solaxpower.com.

SolaX retains all rights for the final explanation.

Scope of Validity

This manual is an integral part of X1-Hybrid-LV series inverter. It describes the transportation, storage, installation, electrical connection, commissioning, maintenance and troubleshooting of the product. Please read it carefully before operating.

This manual is valid for the following inverter models:

- X1-Hybrid-3.0-LV
- X1-Hybrid-3.7-LV
- X1-Hybrid-4.0-LV
- X1-Hybrid-4.6-LV
- X1-Hybrid-5.0-LV
- X1-Hybrid-6.0-LV

Model description



Item	Meaning	Description	
1	Product family name	inverter which support photovoltaic grid-	
2	Power	"3.0": rated output power of 3.0 kW.	
4	Voltage	"LV": low voltage.	

Target Group

The installation, maintenance and grid-related setting can only be performed by qualified personnel who:

- Are licensed and/or satisfy state and local jurisdiction regulations.
- Have good knowledge of this manual and other related documents.

Conventions

The symbols that may be found in this manual are defined as follows.

Symbol	Description
DANGERIndicates a hazardous situation which, if not will result in death or serious injury.	
	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE!	Provides tips for the optimal operation of the product.

Change History

Version 01 (2024-01-12)

Updated the whole manual to a new template.

Updated the content and diagram in "8.6.3 Parallel Connection".

Updated "2.7 Work Mode" and "10 Operation on LCD".

Version 00 (2023-09-27)

Initial release

Table of Contents

1	Saf	Safety1		
	1.1	Gener	al Safety	1
			Instructions of PV, Inverter and Grid	
		1.2.1	Safety Instructions of PV	
		1.2.2	Safety Instructions of Inverter	
		1.2.3	Safety Instructions of Utility Grid	
2	Pro	duct	Overview	4
	2.1	Produ	ct Introduction	4
	2.2	Suppo	rted Power Grid	4
	2.3	Appea	rance	5
		2.3.1	Dimensions	6
		2.3.2	Control Panel	6
	2.4	Symbo	ols on the Label and Inverter	8
	2.5	Workir	ng Principle	9
		2.5.1	Circuit Diagram	9
		2.5.2	Application Schemes	10
	2.6	Workir	ng State	12
	2.7	Workir	ng Mode	12
		2.7.1	Self consumption mode	12
		2.7.2	Backup Mode	13
		2.7.3	Time of use mode	14
		2.7.4	SUB Mode	14
		2.7.5	SBU Mode	15
		2.7.6	MKS Mode	16
3	Sys	tem C	Overview	17
4	Tra	nspor	tation and Storage	19
5	Pre	parati	on before Installation	20
	5.1	Select	ion of Installation Location	20
		5.1.1	Environment Requirement	20
		5.1.2	Installation Carrier Requirement	21
		5.1.3	Clearance Requirement	22
	5.2	Tools	Requirement	23
	5.3	Additio	onally Required Materials	24

6	Unpacking and Inspection	25		
	6.1 Unpacking			
	6.2 Scope of Delivery			
7	Mechanical Installation			
	7.1 Dimensions for mounting	29		
	7.2 Installation procedures			
8	Electrical Connection	33		
	8.1 Terminals of Inverter			
	8.2 PE Connection			
	8.3 AC Connection			
	8.4 PV Connection			
	8.5 Battery Power Cable Connection			
	8.5.1 Battery connection	51		
	8.5.2 Battery temperature sensor connection	56		
	8.6 Communication Connection	58		
	8.6.1 CT/meter port connection	58		
	8.6.2 BMS/DRM/COM port connnection			
	8.6.3 Parallel Connection	68		
	8.6.4 Dry-contact output connection	71		
	8.7 Monitoring Connection	73		
9	System Commissioning	77		
	9.1 Checking before Power-on	77		
	9.2 Powering on the System	77		
	9.3 Checking after Power-on	78		
10	Operation on LCD	79		
	10.1 Introduction of Control Panel	79		
	10.2 Screen Menu Structure	81		
	10.3 LCD Operation Settings			
	10.3.1 Root menu			
	10.3.2 Main menu	82		
11	Operation on SolaX App and Web	90		
	11.1 Introduction of SolaXCloud	90		
	11.2 Operation Guide on SolaXCloud App			
	11.2.1 Downloading and installing App			
	11.3 Operation Guide on SolaXCloud Web			
12	Troubleshooting and Maintenance	92		

	12.1 Troubleshooting	92
	12.2 Maintenance	99
	12.3 Firmware Upgrade	100
	12.3.1 Upgrade preparation	100
	12.3.2 Upgrade steps	100
13	Decommissioning	102
	13.1 Power off	102
	13.2 Disassembling the Inverter	103
	13.3 Packing the Inverter	104
	13.4 Disposing of the Inverter	104
14	Technical Data	105
	14.1 DC Input	105
	14.2 AC Input&Output	105
	14.3 EPS Output	105
	14.4 Battery Data	106
	14.5 System Data	106
	14.6 Protection Device	106
	14.0 FIOLECTION DEVICE	100
	14.7 Power Consumption & Environment Limit	

1.1 General Safety

The series inverter has been meticulously designed and thoroughly tested to comply with all relevant state and international safety standards. Nevertheless, like all electrical and electronic equipment, safety precautions must be observed and followed during the installation of the inverter to minimize the risk of personal injury and ensure a safe installation.

Please thoroughly read, comprehend, and strictly adhere to the comprehensive instructions provided in the user manual and any other relevant regulations prior to the installation of the inverter. The safety instructions in this document serve as supplementary guidelines to local laws and regulations.

SolaX shall not be liable for any consequences resulting from the violation of the storage, transportation, installation, and operation regulations outlined in this document. Such consequences include, but are not limited to:

- Inverter damage caused by force majeure events, such as earthquakes, floods, thunderstorms, lightning, fire hazards, volcanic eruptions, and similar events.
- Inverter damage due to human causes.
- Usage or operation of the inverter in violation of local policies or regulations.
- Failure to comply with the operation instructions and safety precautions provided with the product and in this document.
- Improper installation or usage of the inverter in unsuitable environmental or electrical conditions.
- Unauthorized modifications to the product or software.
- Inverter damage occurring during transportation by the customer.
- Storage conditions that do not meet the requirements specified in this document.
- Installation and commissioning performed by unauthorized personnel who lack the necessary licenses or do not comply with state and local jurisdiction regulations.

1.2 Safety Instructions of PV, Inverter and Grid

Save these important safety instructions. Failure to do so may result in damage to the inverter and injury or even loss of life.

1.2.1 Safety Instructions of PV

\Lambda DANGER!

Potential risk of lethal electrical shock associated with the photovoltaic (PV) system

- Exposure to sunlight can result in the generation of high DC voltage by PV modules, which can lead to electric shock causing severe injuries or even death.
- Never touch the positive or negative poles of the PV connecting device, and avoid touching both poles simultaneously.
- Do not ground the positive or negative poles of the PV modules.
- Only qualified personnel can perform the wiring of the PV modules.

\Lambda warning!

- Overvoltage protection with surge arresters should be provided when the PV system is installed. The grid connected inverter is fitted with SPDs on both PV input side and MAINS side.
- Please consult professionals before installing SPDs.

\Lambda warning!

• Make sure that the input DC voltage does not exceed the maximum DC input voltage specified for the inverter. Overvoltage can cause irreversible damage to the inverter, and such damage is not covered by the warranty.

1.2.2 Safety Instructions of Inverter

\Lambda DANGER!

Potential risk of lethal electrical shock associated with the inverter

- Only operate the inverter if it is in a technically faultless condition. Operating a faulty inverter may lead to electric shock or fire.
- Do not attempt to open the enclosure without authorization from SolaX. Unauthorized opening of the enclosure will void the warranty and can result in lethal danger or serious injury due to electric shock.
- Make sure that the inverter is reliably grounded before any operation to prevent the risk of electric shock causing lethal danger or serious injury.
- Only qualified personnel can perform the installation, wiring, maintenance of the inverter by following this document and the related regulations.

WARNING!

- During operation, avoid touching any parts of the inverter other than the DC switch and LCD panel (if any).
- Never connect or disconnect the AC and DC connector while the inverter is running.
- Prior to conducting any maintenance, turn off the AC and DC power and disconnect them from the inverter. Wait for 5 minutes to fully discharge the energy.

\Lambda warning!

Potential danger of scalding due to the hot enclosure of the inverter

• Avoid touching the inverter while it is running, as it becomes hot during operation and may cause personal injuries.

\Lambda warning!

• When handling the battery, carefully follow all safety instructions provided in the battery manual. The battery used with the inverter must meet the specified requirements of the series inverter.

- Make sure that children are supervised to prevent them from playing with the inverter.
- Pay attention to the weight of the inverter and handle it properly to avoid personal injuries.
- Use insulated tools when installing the device, and always wear personal protective equipment during installation and maintenance.

NOTICE!

- If an external Residual Current Device (RCD) is required by local regulations, verify the type of RCD required. It is recommended to use a Type-A RCD with a rating of 300 mA unless a lower value is required by the specific local electric codes. When required by local regulations, the use of an RCD type B is permitted.
- Keep all product labels and the nameplate on the inverter clearly visible and wellmaintained.

1.2.3 Safety Instructions of Utility Grid

NOTICE!

• Only connect the inverter to the grid with the permission of the local utility grid company.

2.1 Product Introduction

The X1-Hybrid-LV series inverter is a high-quality inverter that combines solar inverter, solar charger, AC charger, and emergency power supply (EPS) function with an IP65 degree of protection. The inverter can be used to optimize self-consumption, store energy in batteries for future use, or feed it into the public grid. The way it operates depends on user preferences.

2.2 Supported Power Grid

There are different ways of wiring for different grid systems. Three grid types, TT / TN-S / TN-C-S are shown as below:




Figure 2-1 Supported power grid TT




Figure 2-2 Supported power grid TN-S




Figure 2-3 Supported power grid TN-C-S

2.3 Appearance




Figure 2-4 Apprearance

Table 2-1	Desciption of	appearance
-----------	---------------	------------

Item	Description	
Nameplate	Nameplate clearly identifies the device type, serial number, specific DC / AC parameters, certification, etc.	
LCD panel	Including screen, indicators and keys. Screen displays the information; indicators indicate the status of inverter. Keys are used to perfom the parameter setting.	
DC switch	Disconnect the DC circuit when necessary.	
Electrical Including PV terminals, battery terminals, AC terminals, connection area communication terminals, etc.		

2.3.1 Dimensions

• Dimension of Inverter




Figure 2-5 Dimension of Inverter

2.3.2 Control Panel

Control Panel of Inverter





* Please refer to the actual product for the color of the LCD screen.

Table 2-2 Definition of keys

Key Definition	
ESC key Exit from the current interface or function	
Up key	Move the cursor to the upper part or increase the value
Down key	Move the cursor to the lower part or decrease the value
Enter key Confirm the selection	

LED indicator	Status		Definition
	•	Solid green	The inverter is in grid-connected operation state or off-grid operation state.
Operating		Green blinking	The inverter is in the process of grid connection or off-grid.
	0	Light off	The inverter is in a fault or manual shutdown state.
Ē		Solid blue	The battery is online and the voltage is normal.
Battery	0	Light off	Low battery voltage or no battery.
		Solid red	The inverter is in fault status.
\triangle		Red blinking	The inverter has alarm information.
Error	0	Light off	There are no faults and alarms in the inverter.
NOTICE!			

Table 2-3 Definition of indicators of Inverter

• While upgrading, the green, blue and red indicator lights will flash in turns, indicating that the upgrade is in progress.

2.4 Symbols on the Label and Inverter

Table 2-4 Description of symbols

otion
rk. verter complies with the requirements of the applicable CE nes.
ertified.
mark. verter complies with the requirements of the applicable UKCA nes.
nark. verter complies with the requirements of the applicable RCM nes.
onal grounding point
e of hot surface. t touch a running inverter, as the inverter becomes hot during ion!
electric shock. oltage exists after the inverter is powered on!
danger ial hazards exist after the inverter is powered on!
ve enclosed document.
verter can not be disposed together with the household waste.
operate this inverter until it is isolated from battery, mains and on- generation source.
r to life due to high voltage. al voltage exists after the inverter is powered off, which needs 5 es to fully discharge. Wait 5 minutes before attempting any service.

2.5 Working Principle

2.5.1 Circuit Diagram

The inverter is equipped with multi-channel MPPT for DC input to ensure maximum power even under different photovoltaic input conditions. The inverter unit converts direct current into alternating current that meets the requirements of the power grid and feeds it into the power grid. The lightning arrester at AC / DC side realizes the function of surge protection. The principle design of inverter is shown in the figure below:




Figure 2-7 Circuit Diagram for X1-Hybrid-LV series inverter

2.5.2 Application Schemes

The series inverter is a high-quality inverter that combines solar inverter, solar charger, AC charger, and emergency power supply (EPS) function with an IP65 degree of protection. The inverter can be used to optimize self-consumption, store energy in batteries for future use, or feed it into the public grid. The way it operates depends on user preferences.

Diagram A: Neutral line and PE line are separated from each other, and the emergency load is connected to the EPS port; (For most countries)




Figure 2-8 Wiring methods for most of the countries

Diagram B: Neutral line and PE line are combined together, and the emergency load is connected to the EPS port. (For Australia)




Figure 2-9 Wiring methods for Australia

NOTICE!

- When a power cut occurs suddenly, the inverter connects the N line of the EPS load to the ground through a relay, establishing a fixed zero potential for the EPS load and ensuring the safe use of electricity by users.
- Ensure that the rated power of the EPS load falls within the EPS rated output power range; otherwise, the inverter will issue an overload warning.
- Please verify with the grid operator if there are any special regulations for grid connection.

2.6 Working State

The series inverter has Start, On and Off state.

Table 2-5 Description of working state

State	Description	
Start	The inverter is checking for conditions to enter On state.	
On	The inverter is working normally.	
 The inverter is waiting for the conditions to be met in order enter the Start state. The inverter detects error occurred and prompts error code 		

2.7 Working Mode

There are different work modes of the inverter based on different needs.

Applicable areas	Work modes
Countries other than Pakistan (including India, Vietnam, South Africa, Uzbekistan)	Self consumption mode, backup mode and time of use mode
Pakistan	SUB mode, SBU mode, MKS mode and Time of use mode

For how to set the working mode, please refer to "10.3 LCD Operation Settings".

2.7.1 Self consumption mode

This mode is applicable to countries other than Pakistan.

Application Scenarios:

This mode is suitable for applications where electricity prices are high and solar power generation is not allowed to feed into the grid. Solar power takes priority in supplying the load, with any excess power being stored in the battery for later use.

The load is primarily powered by solar energy, with the battery taking over if solar power is insufficient, and grid power being the final option.

If the PV power exceeds the load power, the excess power will be used to charge the battery.

This mode defaults to zero feed-in control, preventing any power from being fed back into the grid.

Note:

In this mode, when the battery voltage is lower than the settable battery voltage of loadto-grid power supply, the battery will start charging, and the load will be powered by grid, and the battery will be charged in the following modes according to the priority setting of battery charging power supply: **Only Solar charging:** Solar charges the battery, and the load is completely powered by the power grid;

Solar then Utility charging: If there is Solar energy, only Solar energy will charge the battery; if there is no solar energy, the power grid will charge the battery;

Solar+Utility: Same as 2 (Only Utility charging);

When the battery is charged to the battery voltage supplied by the load to the battery, it will return to the normal operation mode.

2.7.2 Backup Mode

This mode is applicable to countries other than Pakistan.

Application Scenarios:

This mode uses the energy storage system as a backup power source and is suitable for applications where power outages are frequent. When the grid is normal, the load is powered by solar and the grid, and the battery is only charged without discharging. When there is a power outage, the energy storage system works in off-grid mode to supply power to important loads.

The load is prioritized to be powered by solar. If the solar power is insufficient, the load is powered by the grid. If the grid is unavailable, the load is powered by the battery + solar in off-grid mode.

If the PV power is greater than the load power, the excess power charges the battery.

After the battery is fully charged, the excess PV power can be either fed back to the grid or limited based on the zero-export setting.

(In terms of program control, it is consistent with the Self Consumption mode, where the battery charging/discharging power is controlled to be zero or the allowed power for grid feeding. However, the battery only charges and does not discharge.)

Note:

In this mode, if the priority setting for the battery charging source is:

Only Solar charging: No response, and the normal operating mode mentioned above is followed.

Solar then Utility charging: If solar power is available, only solar charges the battery. In the absence of solar power, the grid charges the battery.

Solar + Utility: Same as mode 2 (Only Utility charging).

2.7.3 Time of use mode

This mode is applicable to all countries including Pakistan.

Application Scenarios:

This mode is more suitable for applications with peak and off-peak electricity price differences. When the electricity price is high, the battery discharges to power the load. When the electricity price is low, the battery is charged from solar or the grid to reach full capacity.

It provides three battery discharge time slots, corresponding to peak periods with higher electricity prices. During these periods, the battery discharges to power the load, providing economic value to the customer. The operation during these periods is consistent with the normal operation mode of the Self Consumption mode. The difference lies in the fact that when the battery voltage drops below the voltage at which the load is switched to grid power in the Time of Use mode, the battery only charges without discharging.

Note:

In this mode, it also provides three battery charging time slots, corresponding to off-peak periods with lower electricity prices. During these periods, the battery is charged from PV or the grid, and the load is powered by the grid, providing economic value to the customer. Different priority settings for the battery charging source can be selected for each of the three battery charging time slots, and it is possible for the battery to reach full capacity and enter the float charging stage during these time slots.

Outside the peak and off-peak time slots set, the battery follows the priority setting mode for the battery charging source.

2.7.4 SUB Mode

This mode is applicable under Pakistan's safety, corresponding to backup mode for other countries.

Application Scenarios:

This mode uses the energy storage system as a backup power source and is suitable for applications with frequent power outages. When the grid is operational, the load is powered by solar and the grid, and the battery only charges without discharging. With the grid available, the battery is generally kept at full charge. It only operates in off-grid mode to supply power to critical loads when the grid power is cut off.

The load is primarily powered by solar, and if solar power is insufficient, the grid supplies power. In the absence of grid power, the system switches to off-grid mode, using the battery and solar to power the load.

If the power generated by solar exceeds the load demand, the excess electricity is used to charge the battery.

After the battery is fully charged, whether the surplus PV power is fed back into the grid or limited depends on the setting for zero-export at the grid interface.

Note:

In this mode, if the priority setting for the battery charging source is as follows:

Only Solar Charging: No response, and the normal operation mode described above is followed.

Solar then Utility Charging: If solar power is available, the battery is exclusively charged by solar. In the absence of solar power, the grid charges the battery based on the maximum allowable grid charging current set at the grid interface.

Solar + Utility Charging: The battery is charged using the power from solar plus the maximum allowable grid charging current set at the grid interface.

2.7.5 SBU Mode

This mode is applicable under Pakistan's safety, corresponding to self consumption mode for other countries.

Application Scenarios:

This mode is suitable for applications where electricity prices are high and solar power cannot be fed into the grid. Solar power is prioritized for loads, and excess power is stored in the battery for later use. This mode is ideal for customers with low daytime electricity consumption and higher nighttime electricity consumption.

Loads are primarily powered by solar energy. If the solar power is insufficient, the battery will provide power. If the battery voltage drops below the voltage threshold for switching to grid supply in SBU mode, the loads will be powered by the grid. Once the battery voltage reaches the voltage threshold for switching back to solar and battery supply, the loads will be powered by solar power and the battery again.

If the solar power generated exceeds the load demand, the excess power will be used to charge the battery.

In this mode, zero export is enabled by default, meaning power cannot be fed back to the grid.

Note:

In this mode, if the battery voltage drops below the adjustable voltage threshold for switching to grid supply, the battery starts charging and the loads are powered by the grid. The battery charging mode depends on the priority settings:

Only solar charging: The battery is charged with solar power, and the loads are fully powered by the grid.

Solar then utility charging: If solar power is available, the battery is charged only with solar power. If there is no solar power, the battery is charged within the maximum current limit set for grid charging.

Solar + utility charging: The power generated by solar plus the maximum current limit set for grid charging on the interface will charge the battery simultaneously.

2.7.6 MKS Mode

This mode is applicable under Pakistan's safety.

Application Scenarios:

This mode is suitable for customers who have higher electricity consumption during certain periods of the day and lower consumption at night. When solar power is available, this mode is basically the same as the SBU mode, and the discharge range of the battery is wider than that of the SBU mode. The difference lies in the fact that the battery only starts charging and the load switches to grid power when the battery voltage falls below the minimum discharge voltage. Normal operation is resumed only when the battery is charged to a voltage higher than the maximum charging voltage.

At night when solar power is unavailable, this mode is basically the same as the SUB mode, with the battery only charging and not discharging, which prevents the battery from being depleted.

3 System Overview

System Overview




Figure 3-1 System overview diagram

	Table 3-1 System item description
Item	Description
X1-Hybrid-LV series (the device covered in this manual)	The series inverter combines solar inverter, solar charger, AC charger and emergency power supply (EPS) function together with IP65 degree of protection. The inverter can be used to optimize self-comsumption, stored-in batteries for future use or fed into the public grid. The way it works depends on user preferences.!
PV String	For 3 kW to 6 kW inverter, the number of PV string is two.
Battery	The series inverter should pair with low voltage battery.
СТ	CT is a device that monitors the input and output current of the grid.
Grid	220V/230V/240V grid are supported.
Grid-tied Inverter	A grid-connected inverter is adevice that converts direct current into alternating current, used to integrate the electricity generated by solar panels or other renewable energy systems into the power grid.
Diesel Generaton	The generator is a machine for producing electricity.
SolaX Cloud	SolaX Cloud is an intelligent, multifunctional monitoring platform that can be accessed either remotely or through a hard wired connection. With the SolaX Cloud, the operators and installers can always view key and up-to-date data.

·~+~ Table 7 1 C مام ovinti

4 Transportation and Storage

If the inverter is not put into use immediately, the transportation and storage requirements needs to be met:

Transportation

- Observe the caution signs on the packaging of inverter before transportation.
- Pay attenting to the weight of inverter. Be cautious to avoid injury when carrying X1-Hybrid-LV (gross weight: 20 kg). Four installers or lifting equipment are recommended.
- Wear protective gloves when carrying the equipment by hand to prevent injuries.
- When lifting up the inverter, hold the handle position and the bottom position of the inverter. Keep the inverter horizontal in case of falling down.



Figure 4-1 Caution signs on the packaging

Storage

- The inverter must be stored indoors.
- Do not remove the original packaging material and check the outer packaging material regularly.
- The storage temperature should be between -25°C and +70°C . The humidity should be between 0% and 100%.
- Stack the inverter in accordance with the caution signs on the inverter carton to prevent their falling down and device damage. Do not place it upside down.


5.1 Selection of Installation Location

The installation location selected for the inverter is quite critical in the aspect of the guarantee of machine safety, service life and performance. It has the IP65 ingress protection, which allows it to be installed outdoor. The installation position shall be convenient for wiring connection, operation and maintenance.

5.1.1 Environment Requirement

Make sure the installation site meets the following conditions:

- The ambient temperature: -25℃ to +60℃.
- The relative humidity shall be between 0-100%RH.
- Do not install the inverter in the areas where the altitude exceeds 3000 m.
- Install the inverter in a well-ventilated environment for heat dissipation. You are recommended to install an awning over the inverter if it is installed on a support outdoor.
- Do not install the inverter in areas with flammable, explosive and corrosive materials or near antenna.
- Avoid direct sunlight, rain exposure and snow laying up.



 Install the inverter at least 500 meters away from the coast and avoid sea breeze directly.




Figure 5-1 Recommended installation position




Figure 5-2 Incorrect installation position



5.1.2 Installation Carrier Requirement

The installation carrier must be made of a non-flammable material, such as solid brick, concrete, etc. and be capable of supporting the weight of the inverter and suitable of the dimensions of the inverter. If the wall strength is not enough, (such as wooden wall, the wall covered by thick layer of decoration) it must be strengthened additionally.

Please take the weight of battery into account when wall-mouting the whole system.



Figure 5-3 Installation carrier requirement

5.1.3 Clearance Requirement

The minimum clearance reserved for the connected terminal at the bottom of inverter should be 10 cm. When planning installation space, it is important to simultaneously consider the bending radius of the wires.

To guarantee proper heat dissipation and ease of disassembly, the minimum space around the inverter must meet the standards indicated below.

If you choose stack installation, please refer to the installation separation distance below. In areas with high ambient temperatures, increase the clearances between the inverters and provide adequate fresh air ventilation if feasible.




Figure 5-4 Clearance requirement for single inverter




Figure 5-5 Clearance requirement for multiple inverter

5.2 Tools Requirement

Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site.



5.3 Additionally Required Materials

Table 5-2	Additionally	required	wires
-----------	--------------	----------	-------

No.	Required	Material	T	уре			luctor s-section
1	PV wire	(edicated PV w ating of 600 V	ire with a volt	age 4 mn	n²
2	Commun wire 1	ication	N N	etwork cable	CAT5E	0.2 m	nm²
3	Additoina wire	I PE	W1	onventional y /ire	vellow and gr	reen 4 mn	n²-10 mm²
4	Battery po cable	ower	6 °	onventional o	copper wire		5mm² or 0 mm²
		Table 5-3 C	Grid cable a	nd micro-bre	aker recomn	nended	
	Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
Cabl	e (copper)	4-6 mm ²	6-8 mm ²	6-8 mm ²	8-10 mm ²	8-10 mm ²	8-10 mm ²
Cicu	uit breaker	32 A	40 A	40 A	50 A	50 A	50 A
		Table 5-4	EPS cable a	nd micro-bre	aker recomm	nended	
	Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
Cable	e (copper)	3-4 mm ²	3-4 mm ²	3-4 mm ²	4-6 mm ²	4-6 mm ²	6-8 mm ²
Micro	-Breaker	25 A	25 A	25 A	32 A	32 A	40 A
		Table 5-6 C	GEN cable a	nd micro-bre	aker recomr	nended	
	Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
Cable	e (copper)	3-4 mm ²	3-4 mm ²	3-4 mm ²	4-6 mm ²	4-6 mm ²	6-8 mm ²
Micro	o-Breaker	25 A	25 A	25 A	32 A	32 A	40 A

6 Unpacking and Inspection

6.1 Unpacking

- The inverter undergoes 100% testing and inspection before shipping from the manufacturing facility. However, transport damage may still occur. Before unpacking the inverter, please check the outer packing materials for damage, such as holes and cracks.
- Unpacking the inverter according to the following figure.







Figure 6-1 Unpacking the inverter


- Be careful when dealing with all package materials which may be reused for storage and relocation of the inverter in the future.
- Upon opening the package, check whether the appearance of the inverter is damaged or lack of accessories. If any damage is found or any parts are missing, contact your dealer immediately.


6.2 Scope of Delivery


























Table 6-1 Packing list

Item	Description	Quantity
/	Inverter	1 pc
/	Wall mounting bracket	1 pc
А	Negative PV connectors	2 pcs
В	Negative PV pin contacts	2 pcs
С	Positive PV connectors	2 pcs
D	Positive PV contacts	2 pcs
E	Expansion tubes	3 pcs
F	Self-tapping screws	3 pcs

Item	Description	Quantity
G	Washers	3 pcs
Н	Battery connection terminals	2 pcs
I	Y terminals	9 pcs
J	OT terminal	1 pc
К	M4*12 Screws	4 pcs
L	RJ45 connectors	2 pcs
М	RJ45 terminals	4 pcs
Ν	Document	/
0	Battery temperature sensor	1 pc
Ρ	CT (CT cable: 50 cm)	1 pc
Q	Tool Wrench	1 pc
/	Dongle (Optional)	1 pc
/	Meter (Optional)	1 pc

- Please refer to the actual delivery for the optional accessories.
 The figures of packing list take X1-Hybrid-3.0-LV inverter as an example.

7 Mechanical Installation

🕂 WARNING!

- Only the qualified personnel can perform the mechanical installation following the local standards and requirements.
- Check the existing power cables or other piping in the wall to prevent electric shock or other damage.

- Always be aware of the weight of the inverter. Personal injuries may result if the inverter is lifted improperly or dropped while being transported or mounted.
- Use insulated tools when installing the inverter. Personal protective equipment must be worn during installation and maintenance.

NOTICE!

• Install the inverter at a maximum back tilt of 5 degrees and avoid forward tilted, side tilted, or upside down.




Figure 7-1 Correct installation




Figure 7-2 Incorrect installation

7.1 Dimensions for mounting

Check the dimensions of the wall mounting bracket before mounting and reserve sufficient space for heat dissipation and installation of the whole system.




Figure 7-3 Dimensions 1 (Unit: mm)




Figure 7-4 Dimensions 2 (Unit: mm)

7.2 Installation procedures

Step 1: Align the wall mounting bracket horizontally on the wall and mark the position of the drill holes.




Figure 7-5 Marking the holes

NOTICE!

- Take the height of the battery into account when mounting the wall mounting bracket.
- Observe the bubble of spirit level and adjust the wall mounting bracket until the bubble stays in the middle.
- **Step 2:** Set the wall mounting bracket aside and drill holes with Ø10 drill bit. The depth of the holes should be greater than 80 mm. The Hammer drill needs to be 90° perpendicular to the wall when using it. Do cover the inverter before drilling holes and clean up any dust in and around the holes using a dust collector.




Figure 7-6 Drilling holes

Step 3: Attach the wall mounting bracket on the wall again. Insert the expansion bolt into the holes and secure the wall bracket to the wall with expansion screws.




Figure 7-7 Insert the expansion bolt




Figure 7-8 Securing the wall mounting bracket

- **Step 4:** Open the anti-static bag and take out the machine.
- **Step 5:** Lift up the inverter by three installers and hang it on the wall mounting bracket. The keyways of the inverter must be hooked into the buckles of wall mounting bracket.




Figure 7-9 Hanging the inverter

Step 6: Secure the inverter to the wall mounting bracket with M4 screws. Tighten the M4 screws on both sides.




Figure 7-10 Securing the inverter

NOTICE!

• If the inverter is temperally needed to be placed on the ground, use foam or other protective materials to prevent any damage of inverter.

8 Electrical Connection

🕂 DANGER!

• Before electrical connection, make sure the DC switch and AC breaker are disconnected. Otherwise, electrical shock may be caused by high voltage, resulting in serious personal injury or death.

WARNING!

- Only the qualified personnel can perform the electrical connection following the local standards and requirements.
- Follow this manual or other related document to wire connection. The inverter damage caused by incorrect cabling is not in the scope of warranty.

• Use insulated tools and wear individual protective tools when connecting cables.

8.1 Terminals of Inverter




Figure 8-1 Terminals of Inverter (Front perspective view)




Figure 8-2 Terminals of Inverter (Bottom view 1)




Figure 8-3 Terminals of Inverter (Bottom view 2)

Table 8-1	Description	of terminals
-----------	-------------	--------------

ltem	Description
1	Communication ports
2	Battery input connectors
3	Dry-contact output
4	Grid
5	EPS
6	Generator input
7	Battery power on button
8	DC Switch
9	PV input with two MPPT

Item	Description
10	Waterproof valve
11	BAT+/BAT-
12	USB port for upgrading/External monitoring connection port
13	Overload reset button
14	COM1/COM2/COM3 (for communication connection)
15	Fan (Only for X1-Hybrid-5.0-LV and X1-Hybrid-6.0-LV)

8.2 PE Connection

All non-current carrying metal parts of the equipment and other enclosures in the PV system must be grounded reliably. The PE point at the AC output terminal is used only as a PE equipotential point, not a substitute for the PE point on the enclosure. The connection

point has been labeled with the following label: (We recommend that the inverter is

earthed to a nearby ground point.

PE connection procedures

Step 1: Prepare a one-core cable (4-10 mm²), and then find the OT terminal in the accessories. Strip the grounding cable insulation (length:10-12 mm).




Figure 8-4 Striping the PE cable

Table 8-2	PE cable red	commended
-----------	--------------	-----------

Model	X1-HYB- 3.0-LV		X1-HYB- 4.0-LV	X1-HYB- 4.6-LV		X1-HYB- 6.0-LV
PE Cable	4-6 mm ²	6-8 mm ²	6-8 mm ²	8-10 mm ²	8-10 mm²	8-10 mm²

NOTICE!

- When AC cable $\leq 16 \text{ mm}^2$, the earthing conductor should be as thick as the AC cable...
- **Step 2:** Pull the heat-shrink tubing over the PE cable and insert the stripped section into the OT terminal.




Figure 8-5 Installing the tubing and OT teriminal

Step 3: Crimp it with crimping tool, pull the heat-shrink tubing over the stripped section of the OT terminal and use a heat gun to shrink it so that it can be firmly contacted with the terminal.




Figure 8-6 Crimping the cable




Figure 8-7 Shrinking the tubing

Step 4: Find the ground connection port on the inverter, loosen the PE screw on the inverter with cross screwdriver and screw the ground wire on the inverter with a cross screwdriver.




Figure 8-8 Securing the PE cable

8.3 AC Connection

NOTICE!
• The series inverter is a single-phase inverter suitable for rated voltages of 220/230/240V and frequencies of 50/60Hz. For more technical requirements, please
consult the regulations of the local public grid.
• A circuit breaker should be installed between the inverter and the mains, and the load

• A circuit breaker should be installed between the inverter and the mains, and the load should not be directly connected to the inverter.

The series inverters have an integrated EPS (Emergency Power Supply) function. When the grid is connected, the inverter outputs flow through the Grid port; when the grid is disconnected, the inverter outputs flow through the EPS port.

Please refer to "2.5.2 Application Schemes" for wiring information.

To ensure compatibility with all loads, additional accessories are required. Please Refer to "5.3 Additionally Required Materials". If you need a solution, please contact our sales.




Figure 8-1 Wrong connection of load and inverter

EPS load requirements

The following table shows some common loads for your reference. Please check with the manufacturer for high-power inductive loads.

	Power			Instance		
Content Start		Rated	Common equipment	Equipment	Start	Rated
Resistive load	X 1	X 1	Incandescent lamp	100W	100VA (W)	100VA (W)
Inductive load	X 3~5	Х 2	Fan Fridge	150W Fridge	450- 750VA (W)	300VA (W)

Table 8-3 Description of terminals

- Ensure that the EPS load's rated power is within the EPS rated output power range; otherwise, the inverter will report an overload warning.
- If an overload occurs, adjust the load power to ensure it is within the EPS rated output power range, and the inverter will automatically return to normal operation.
- For non-linear loads, ensure that the inrush current power is within the EPS rated output power range.

Grid, GEN and EPS connection steps

NOTICE!

- Please see "14 Technical Data" to check the grid voltage and compare with the voltage range.
- Remember to disconnect all power sources to prevent electric shock.
- **Step 1:** Prepare a grid cable (triple-core cable), an EPS cable (triple-core cable), and a GEN cable (triple-core cable). Then, find the Y Terminals in the accessory bag. (Using X1-HYB-3.0-LV as an example)




Figure 8-2 Striping the Grid cable

NOTICE!

- Please refer to the table in 5.3 Additionally required materials to view the recommended wire sizes for GRID, EPS, and GEN.
- It is recommended to use copper wire. Non-triple or non-dual core cables shall be sealed with glue or fireproof mud.
- When using wire sizes of 6 mm² and above, only 2-core wires can be used because the 3-core wire cannot pass through the waterproof terminal. In the case of using 2-core wire, the PE wire should only be connected to the inverter shell and does not need to be connected to the internal terminals.
- All connection diagrams provided here are based on the use of a 3-core wire, with X1-HYB-3.0-LV serving as an example.

Step 2: Use a cross screwdriver to loosen the screws on both sides of the inverter. Remove the lower cover of the inverter.




Figure 8-3 Loosen the screws




Figure 8-4 Remove the lower cover

Step 3: Remove the plug of Grid, GEN and EPS ports.




Figure 8-5 Remove the plug

Step 4: Find the location of the AC interface. The Grid, GEN, and EPS connection port are shown below.




Figure 8-6 Find the Location

Step 5: Pass the previously prepared Grid, GEN and EPS cables through the corresponding screw caps and seals rings. The Grid, GEN, and EPS cables should go through the corresponding Grid, GEN, and EPS ports.




Figure 8-7 Pass the Grid cable




Figure 8-8 Pass the GEN cable




Figure 8-9 Pass the EPS cable

Step 6: Remove the 10 mm insulation layer at the end of the wire. Insert the fork terminals respectively, and make sure that the stripped ends are inserted into the fork terminal, and finally use crimping pliers to press tightly.




Figure 8-10 Remove the layer




Figure 8-11 Insert and press the terminal

Step 7: Insert the crimped cables into the corresponding L, N, and PE terminals according to the wire sequence and tighten the screws with a cross screwdriver. Twist to tighten the screw caps and seals rings.




Figure 8-12 Insert the Grid cable




Figure 8-13 Tighten the Grid cable




Figure 8-14 Grid cable connected




Figure 8-15 Insert the GEN cable




Figure 8-16 Tighten the GEN cable




Figure 8-17 GEN cable connected




Figure 8-18 Insert the EPS cable




Figure 8-19 Tighten the EPS cable




Figure 8-20 EPS cable connected

8.4 PV Connection

The series inverters have two PV inputs. Please select photovoltaic modules with good performance and quality assurance. The open circuit voltage of the module array should be less than the maximum PV input voltage specified by the inverter, and the working voltage should be within the MPPT voltage range.

Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
Max. PV input voltage		550V				
Start output voltage	110V					
Nominal input voltage	360V					
MPPT voltage range	80V ~ 520V					

DANGER!

- Photovoltaic modules operate at high and potentially dangerous voltages, so it is essential to follow safe electrical regulations when wiring them.
- High DC voltage will be generated by PV modules when exposed to sunlight. Death or lethal injuries will occur due to electric shock.
- Make sure the DC switch and AC breaker are disconencted from the inverter before connection.
- Make sure that the PV module output is well insulated to ground.

• Do not ground the positive or negative pole of the photovoltaic module!

🔨 WARNING!

• To mitigate the risk of fire, it is crucial to utilize a dedicated crimping tool specifically designed for PV installations to ensure secure and reliable connections.

NOTICE!

• For each input range, the following PV module requirements must be met: same model, same quantity, and same angle.

Requirements for PV connection

- The series inverters support the following PV module connection modes.
 - » Method : Multi




Figure 8-21 Striping the PV cable

Wiring procedures

Step 1: Turn off the DC switch, prepare a 4 mm² PV cable, and find the PV (+) terminal and PV (-) terminal in the package. Strip approx. 7 mm of the cable insulation.




Figure 8-22 Striping the PV cable

Step 2: Insert the stripped cable into the PV pin contact. Ensure that the stripped cable and the PV pin contact are of the same polarity. Crimp it with crimping tool for PV terminal.




Figure 8-23 Inserting the PV pin contact






Figure 8-24 Crinping the terminal

\Lambda WARNING!

- To mitigate the risk of fire, it is crucial to utilize a dedicated crimping tool specifically designed for PV installations to ensure secure and reliable connections.
- **Step 3:** Thread the PV cable through swivel nut and insert the cable into the PV connector until a "Click" is heard. Gently pull the cable backward to ensure firm connection. Tighten the swivel nut clockwise. Verify that the PV connectors have the correct polarity before connection. Use the tool wrench if you need to unlock.








Figure 8-26 Securing the PV cable




Figure 8-27 Unlocking the PV cable

Step 4: Use a multimeter to measure the positive and negative voltage of the assembled PV connectors. Make sure the open circuit voltage does not exceed the input limit of 500 V.




Figure 8-28 Measuring the voltage of PV connectors

NOTICE!

- If the voltage reading is negative, it indicates an incorrect DC input polarity. Please check if the wiring connections on the multimeter is correct or PV connectors are not mistakenly connected.
- **Step 5:** Remove the PV terminal caps and connect the assembled PV connectors to corresponding terminals until there is an audible "Click". The PV+ on the string side must be connected to the PV+ on the inverter side, and the PV– on the string side must be connected to the PV– on the inverter side.




Figure 8-29 Connecting the PV cable

WARNING!

• Seal the unused PV terminals with original terminal caps. If all PV terminals are connected, keep the waterproof caps in a safe place. Reinstall it immediately after removing the connectors from terminals.

8.5 Battery Power Cable Connection

8.5.1 Battery connection

Battery tconnection diagram

Model	X1-HYB-3.0-LV	X1-HYB-3.7-LV	X1-HYB-4.0-LV	X1-HYB-4.6-LV	X1-HYB-5.0-LV	X1-HYB-6.0-LV
Recommended battery capacity (kWh)		3.7 ~ 5.55	4.0 ~ 6.0	4.6 ~ 6.9	5.0 ~ 7.5	6.0 ~ 9.0




Figure 8-30 Battery connection diagram

Requirments for battery connection

- Required battery
 - » The series inverter system can be equipped with low voltage lithium battery and lead acid battery.
- Battery Breaker
 - » Before connecting the battery, a non-polar DC MCB must be installed to ensure safety.
 - » Before maintenance, the inverter need to be safely disconnected.

Model	X1-HYB-3.0-LV	X1-HYB-3.7-LV	X1-HYB-4.0-LV	X1-HYB-4.6-LV	X1-HYB-5.0-LV	X1-HYB-6.0-LV
Voltage	Nominal voltage of DC breaker should be larger than maximum voltage of battery.					
Current[A]	100 A				150 A	

\Lambda DANGER!

- Make sure the breaker, power button (if any) and DC switch (if any) of battery is OFF.
- Always ensure correct polarity. Never reverse the polarity of the battery cables as this will result in inverter damage.



• Please ensure that the BAT power line and BMS communication line are correctly connected when using the low-voltage batteries TP-LR25 and TP-LR36. Check T-BAT LR25 & T-BA LR36 Installation Manual for details.

Battery connection steps

Step 1: Prepare a 16-25 mm² or 35-50 mm² battery power cable. Strip approx. 10 mm of the cable insulation.




Figure 8-31 Striping the battery cable

Step 2: Insert the stripped cables into the OT terminals respectively and crimp the terminals tightly. Users can find the OT terminals in the accessory bag.




Figure 8-32 Insert the terminal

Figure 8-33

Step 3: Loosen the waterproof connector.




Figure 8-34 Connecting the battery connector

- For battery connection from 3.0 kW to 4.0 kW
- Step 4: Remove the sealing cover of the plug.




Figure 8-35 Remove the sealing cover

Step 5: Pass the previously assembled cables through the corresponding swivel nut. Find the battery interface, insert the positive cable into BAT+ port and the negative cable to BAT-port.




Figure 8-36 Pass and insert the cable

Step 6: Find the battery interface, remove the screw. insert the positive cable into BAT+ port and the negative cable to BAT-port.




Figure 8-37 Remove the screw

Step 7: Use cross screwdriver to tighten the screw. Twist to tighten the swivel nut.




Figure 8-38 Tighten the cable

- For battery connection from 4.6 kW to 6.0 kW
- Step 4: Remove the plug.




Figure 8-39 Remove the plug

Step 5: Pass the previously assembled cables through the corresponding swivel nut. Find the battery interface, insert the positive cable into BAT+ port and the negative cable to BAT-port.




Figure 8-40 Pass and insert the cable

Step 6: Find the battery interface, remove the screw. insert the positive cable into BAT+ port and the negative cable to BAT-port.




Figure 8-41 Remove the screw

Step 7: Use cross screwdriver to tighten the screw. Twist to tighten the swivel nut.




Figure 8-42 Tighten the cable



- Keep the terminal caps in a safe place if batteries are connected to the inverter.
- Reinstall the caps immediately after removing the connectors from terminals.

NOTICE!

• If only the battery is connected but the PV, GRID, and GEN are not connected, to start the inverter, press and hold the battery power on button until the screen is on.

8.5.2 Battery temperature sensor connection

Battery temperature sensor connection diagram




Figure 8-43 Battery temperature sensor connection diagram

Battery temperature sensor connection steps

- Step 1: Find the battery temperature sensor in the accessory bag.
- **Step 2:** Disassemble the swivel nut on COM1/2/3. Pass the battery temperature sensor through the COM port and insert the RJ45 connector of the battery temperature sensor into the BMS port located inside the inverter. You can select any port from COM1/2/3.
- **Step 3:** Attach the terminal at the other end to the lead-acid battery in order to measure the battery temperature.




Figure 8-44 Insert the cable into the BMS port




Figure 8-45 Attach the terminal

8.6 Communication Connection




Figure 8-46 Communication ports

Number	Description		
A	Dry-contact output		
В	DRM(optional)		
С	COM		
D	BMS		
E	Parallel_1		
F	Parallel_2		
G	Meter/CT		

Table 8-5 Definition of communication ports

8.6.1 CT/meter port connection

The inverter should work with an electric meter or current sensor (CT for short) to monitor household electricity usage. The electricity meter or CT can transmit the relevant electricity data to the inverter or platform, which is convenient for users to read at any time.

Users can choose to use electric meters or CTs according to their demand. Please note that the meter/CT brand required by us must be used.

Users can also customize the length of the CT communication cable and the NTC cable (battery temperature sensor). The accessory package provides two RJ45 connectors.

When the CT cable is completed, connect the A terminal to the METER/CT port inside the inverter and securely tighten the waterproof screw. Connect the B terminal to the RJ45 terminal.




Figure 8-47 customize the CT cable

NOTICE!

- The meter or CT must be connected to the inverter; otherwise, the inverter will shut down and trigger a "meter failure" alarm. Smart meters must be authorized by us, third-party, or other companies. Unauthorized meters may be incompatible with the inverter.
- Our company will not be responsible for the impact caused by the use of other appliances.

CT connection diagram

The current sensor measures the current on the live wire between the inverter and the public grid.

• CT connection diagram





Figure 8-48 CT connection diagram

Meter connection diagram

The current sensor measures the current on the live wire between the inverter and the public grid.

• Meter connection diagram





NOTICE!

- If two meters are to be connected in the system, the communication cables of the meters should be connected in parallel. For example, the 485A of one meter should be connected with the 485A of the other meter, and the 485B of one meter should be connected with the 485B of the other meter.
 - Pin definition for CT/Meter



terminal 4 and 5, while the CT cable goes to pin terminals 1 and 8.

CT/Meter connection steps

Step 1: Remove the plug. For Communication connection, you can select any port from COM 1, COM 2 and COM3.




Figure 8-50 Remove the plug

 Step 2: For meter connection, crimp only one RJ45 terminal.
 For CT connection without RJ45 connector, there is no need to crimp another RJ45 terminal.

For CT connection with RJ45 connector, crimp two RJ45 terminal.




Figure 8-51 Crimp the terminal

NOTICE!

- it is recommanded to use CAT5 Cable.
- **Step 3:** For meter connection, insert one side of the cable (with no terminal) into the inverter, and the other side of the cable into the waterproof distribution box.




Figure 8-52 Insert one side of the cable into the inverter




Figure 8-53 Insert the other side of the cable into the waterproof distribution box

Step 4(μ): For CT connection without RJ45 connector, insert one side of the finished cable and the waterproof connectors with RJ45 into the Meter/CT port of the inverter, tighten the waterproof screw and insert the other side of the RJ45 terminal into the CT connection.




Figure 8-54 Insert one side of the cable into the inverter




Figure 8-55 Insert the other side of the cable into the CT connection

Step 4(2): For CT connection with RJ45 connector, connect the A terminal to the Meter/CT port of the inverter, tighten the waterproof screw and connect the B terminal to the RJ45 coupler.




Figure 8-56 Connect the A teminal




Figure 8-57 Connect the B teminal

NOTICE!

- When installing, pay attention to water resistance. All the connected parts of the CT must be placed into the distribution cabinet.
- Do not place the CT on the N wire or ground wire.
- Do not put the CT on both the N line and L line at the same time.
- Do not place the CT on the side where the arrow points to the inverter.
- Do not place the CT on non-insulated wires.
- After the CT is connected, prevent the CT clip from falling off.
- It is recommended to wrap the CT clip with insulating tape.

8.6.2 BMS/DRM/COM port connnection

BMS port definition

Lithium battery connection diagrm




Figure 8-58 Lithium battery connection diagrm

Pin definition for BMS

Pin	1	2	3	4	5	6	7	8
Pin Definition	BMS_485B	BMS_485A	GND	BMS_CANH	BMS_CANL	Х	GND	BAT_TEMP



DRM port definition (Only for Australia)

This inverter can support external control signal response, such as complying with AS4777 regulatory requirements.

Table 8-7 DRM mode				
Mode	Requirements			
DRM0	Operation disconnect device			


Pin definition for DRM

Pin	1	2	3	4	5	6	7	8
Pin Definition	DRM1/5	DRM2/6	DRM3/7	DRM4/8	RG/0	CL/0	Х	Х

COM communication definition

COM communication interface is mainly provided for customization the second step of development use. The inverter supports the control of external equipment or external equipment control through communication. For example, the inverter adjusts the working mode of the heat pump and so on.


• Pin definition for COM



NOTICE!

- Customers can communicate or control the inverter and external devices through the COM interface. Professional users can use pins 4 and 5 to realize data acquisition and external control functions. The communication protocol is Modbus RTU. For details, please contact us.
- If the user wants to use the inverter dry contact to control external equipment (such as a heat pump), it can be used with our Adapter Box. Please refer to the quick installation manual of the Adapter Box for more details.
 - Application occasion

COM is a standard communication interface, through which the monitoring data of the inverter can be directly obtained. Also, external communication devices can be connected to carry out the secondary development of the inverter. For specific technical docking, please contact us.








Figure 8-60 Application occasion: Inverter communication to control external equipment

BMS/DRM/COM connection steps

Step 1: Remove the plug. Pass the cable through the corresponding screw caps and seals rings. Strip the insulation layer (length: 15mm) at one end of the cable. Crimp a RJ45 terminal at the same end of the cable.




Figure 8-61 Prepare the cable

1 8	1	White with orange stripes	5	White with blue stripes
12345678	2	Orange	6	Green
	3	White with green stripes	7	White with brown stripes
	4	Blue	8	Brown

NOTICE!

- It is recommanded to use CAT5 Cable.
- Use network cable tester to test the crimped cable before connecting to the inverter.
- **Step 2:** Find the DRM(optional), COM, BMS port. For comunication connection, you can select any port from COM 1, COM 2 and COM 3. Insert the previously prepared cables into the corresponding ports.




Figure 8-62 Find the DRM(optional), COM, BMS port




Figure 8-63 Insert the cable


NOTICE!

• After the BMS communication between the battery and the inverter is finished, the battery will work normally.

8.6.3 Parallel Connection


The series inverters provide parallel function, and up to 10 inverters can be connected in a system. In this system, one inverter is set as the "master inverter", and the other inverter is switched to the "slave inverter" state, and the inverters are connected to communicate through the parallel line.

The parallel cable making method is the same as BMS/DRM/COM.



System diagram applicable with use of energy meter

Figure 8-64 System diagram applicable with use of energy meter



System diagram applicable with use of current sensor (CT)

Figure 8-65 System diagram applicable with use of current sensor (CT)

Parallel connection diagram





Figure 8-66 Parallel connection diagram

8.6.4 Dry-contact output connection



Dry-contact output connection diagram

Figure 8-67 Dry-contact output connection diagram

Dry-contact definition

DO_1 and DO_2 are dry contact output ports that can be used to start external devices such as generators and adaptor boxs.

Dry-contact output connection steps

Step 1: Strip the insulation layer (length: 15mm) at one end of the cable. And cut off the 6 cables (length:6-8mm), keep the rest 2 cables.
 For dry-contact output connection, you can select any two cables from the following four groups: white with orange stripes, Orange; white with green stripes, blue; white with blue stripes, green; white with brown stripes, brown.

NOTICE!

- It is recommanded to use CAT5 Cable.
- Use network cable tester to test the crimped cable before connecting to the inverter.




Figure 8-68 Prepare the cable

Table 8-8 CAT5 wiring order

1 8	1	White with orange stripes	5	White with blue stripes
12345678	2	Orange	6	Green
	3	White with green stripes	7	White with brown stripes
	4	Blue	8	Brown

NOTICE!

- It is recommanded to use CAT5 Cable.
- Use network cable tester to test the crimped cable before connecting to the inverter.
- **Step 2:** Find DO_1 and DO_2 port. For Communication connection, you can select any port from COM 1, COM 2 and COM3. Insert the prepared cable into the corresponding ports.




Figure 8-69 Find the port




Figure 8-70 Insert the cable

Step 3: Slide to close the lower cover. Use cross screwdriver to tighten the screws on both sides of the inverter.




Figure 8-71 Close the lower cover and tighten the screws

8.7 Monitoring Connection

The inverter provides a DONGLE port, which can transmit data of the inverter to the monitoring website via WiFi Plus Dongle, 4G Dongle, and LAN Dongle.Users can choose based on actual needs. (If needed, purchase products from us.)

Monitoring connection diagram




Figure 8-72 Wi-Fi mode connection diagram




Figure 8-73 LAN mode connection diagram




Figure 8-74 4G mode connection diagram

Monitoring wiring procedure

- WiFi mode:
- Step 1: Assemble the dongle;




Figure 8-75 Assembling the dongle

Step 2: Plug the dongle to the inverter.




Figure 8-76 WiFi connection procedure

\Lambda CAUTION!


• The buckles must be on the same side. Otherwise, the dongle may be damaged.


NOTICE!

- The longest connection distance between the router and the equipment should be no more than 100 meters; if there is a wall between the router and the equipment, the longest connection distance is 20 meters.
- When the WiFi signal is weak, please install a WiFi signal booster at the appropriate location.

NOTICE!

- Please refer to Pocket WiFi + LAN Installation Guide for instructions on configuring the WiFi. It is important to note that the WiFi configuration should be performed after powering on the inverter..
 - LAN mode:
- **Step 1:** Disassemble the waterproof connector into components 1, 2, 3 and 4; Component 1 is not used. Keep it in a safe place;





Step 2: Assemble the dongle;





Figure 8-78 Assembling the LAN dongle

Step 3: Plug the dongle to the inverter.

• DONGLE:






Figure 8-79 Remove the waterproof plug

Step 2: Plug the communication dongle into the DONGLE port. Remind to keep the "QR Code" upwards.




Figure 8-80 Plug the communication dongle

NOTICE!


- The longest connection distance between the router and the equipment should be no more than 100 meters; if there is a wall between the router and the equipment, the longest connection distance is 20 meters.
- When the Wi-Fi signal is weak, please install a Wi-Fi signal booster at the appropriate location.

9.1 Checking before Power-on

- a. Check if the device installed correctly and securely;
- b. Make sure that all the DC breakers and AC breakers are OFF;
- c. All DC, AC cables and communication cables are connected correctly and securely;
- d. The ground cable is connected correctly and securely;
- e. Make sure the meter/CT is connected correctly and securely;
- f. Make sure the battery is connected correctly and securely;
- g. Make sure all photovoltaic panels are connected correctly and securely;
- h. Make sure the external AC and DC connectors are connected;
- i. Unused terminals and ports are locked by waterproof caps. All the screws are tightened.

9.2 Powering on the System

- Step 1: Turn on the grid port load and EPS port load breaker
- Step 2: Turn on the AC breaker between the inverter and wait for the inverter power on.





- **Step 3:** Turn on the DC switch and check the LCD screen.
 - » If the LCD screen is not on, turn off the DC switch and check whether the PV polarity is connected correctly.
 - » If the error of any channel of PV is displayed on LCD, turn off the DC switch and check the corresponding channel of PV connection.




Figure 9-2 Turning on DC switch

- Step 4: Switch on the battery or the breaker, button, DC switch of the battery.
- **Step 5:** Press the button on the inverter. Please note that pressing this button is necessary only when the battery is connected, not when the PV or grid is connected.




Figure 9-3 Pressing the button

Step 6: Check the LCD screen and enter Root Menu>STR >Power On/Off to verify if the inverter can start normally.

WARNING!

• The input terminal of the inverter should be opened only when all the installation work of the inverter has been completed.

9.3 Checking after Power-on

- a. Check whether the inverter has any abnormal noise.
- b. Check whether the indicator lights report an error and whether the LCD screen displays the error message.
- c. Check whether the data of PV, grid and battery are normal through the LCD screen.
- d. Check whether the Work Mode is consistent with what had been set through LCD screen or the SolaX Cloud APP.

10 Operation on LCD

10.1 Introduction of Control Panel




Figure 10-1 Control Panel of the inverter

* Please refer to the actual product for the color of the LCD screen.


Table 10-1 Definition of keys

Кеу	Definition
ESC key	Exit from the current interface or function
Op key	Move the cursor to the upper part or increase the value
O Down key	Move the cursor to the lower part or decrease the value
H Enter key	Confirm the selection

er
6

LED indicator	Status		Definition
Operating	•	Solid green	The inverter is in grid-connected operation state or off-grid operation state.
		Green blinking	The inverter is in the process of grid connection or off-grid.
	0	Light off	The inverter is in a fault or manual shutdown state.

E Battery		Solid blue	The battery is online and the voltage is normal.		
	\bigcirc	Light off	Low battery voltage or no battery.		
		Solid red	The inverter is in fault status.		
Error		Red blinking	The inverter has alarm information.		
	0	Light off	There are no faults and alarms in the inverter.		
NOTICE!					
• While upgrading, the green, blue and red indicator lights will flash in turns, indicating that the upgrade is in progress.					



10.2 Screen Menu Structure

10.3 Settings


10.3.1 Root menu

Basic Settings

The root menu is the default interface, the inverter will automatically return to this interface when the system started up successfully or not operated for a period of time. The information of the interface is as below.

Users can tap on the four circles at the corners to access basic information including PV, battery, grid and load,.

Tapping the "STR" button in the center will navigate to the Power On/Off settings. Users can tap the circles to check basic information of the inverter and battery. "Power On" indicates that the inverter is in working state, which is generally the default state. "Power Off" means that the inverter stops running and only the LCD screen is turned on. To set power on or off, users could tap the selection box and then press " $\sqrt{}$ " to save the settings.



According to the operating conditions of the inverter, the root menu interface will also display differently.

• Inverter starting \rightarrow Inverter already started, ready for operation



Inverter off



Inverter error

If there is a fault currently, one of the faults will be displayed on the main interface. To view details, please enter Main menu "Inverter information" -> "Errors" to check the current and historical faults.



Line Color Explanation

The lines on this interface will also show the corresponding statuses of PV, battery, grid, and load.

Circuit	Status	Color
PV to	Electricity generating	Green
Inverter	Electricity not generating	Grey
	Discharging	Blue
	Stop charging or discharging	Grey
Battery to Inverter	Charging (from PV)	Green
	Charging (from Grid)	Red
	Charging (from PV and Grid)	Orange
	Power consuming	Red
Power grid to inverter	No power in the grid	Grey
	Grid feed-in (PV generation)	Green
	Grid feed-in (PV generation + battery discharge)	Orange

Table 10-3	LCD Display	Colored Line	Explanation
------------	-------------	--------------	-------------


Load to inverter	Load consumption (from PV or battery)	Blue
	Load consumption (from grid)	Red
	Load consumption (from two sources among grid, PV, and battery)	Orange
	Load consumption (power grid, PV and battery supply power to the load at the same time)	Purple

10.3.2 Main menu

To enter the main menu, please tap the settings icon in the upper right corner. There are eight submenus in the menu that can be selected for relevant setting operations.



Work Mode



For mode selection, there are 3 or 4 working modes to choose from depending on different safety options. Please refer to 3.3 Work mode for detailed explanation.

To select the Pakistan work modes, please tap "Country" on the main menu and select "Pakistan". You can refer to "Country" section for details.

Note that the basic settings pages will be different when Pakistan are selected. Please refer to the basic settings section on next page for more details.

Work mode for Pakistan

	Mode Settings	Mode Settings	Mode Settings	Mode Settings
	SUB SBU MKS Time of Use	SUB SBU MKS Time of Use	SUB SBU MKS Time of Use	SUB SBU MKS Time of Use
-		Return To Utility Voltage 48.0 V Return To Battery Voltage 52.0 V	Low DC Cut-off Voltage 48.0 V	
		Confirm	Confirm	

Work mode for other countries



When "Time Of Use" mode is selected, there will be two interface pages for setting the charging period and discharging period. Users can switch between the two pages using the up and down buttons:



Battery settings

Here users can select different battery types, including Solax for SolaX lithium batteries, Cyclone for GSL lithium batteries, Volta for GenixGreen lithium batteries, AGM for lead-acid batteries, FLD for flooded (lead-acid) batteries, TBL for ultra-capacity lead-acid batteries, and USER for user-defined options.

For charging the battery, there are options to choose from: "PV Only" allows only PV charging. "PV Then Utility" prioritizes PV charging and supplements with grid charging when needed. "PV+Utility" allows for both PV and grid charging.

The maximum discharge current of the battery in the range of (0-120A). The maximum charging current of the battery in the range of (0-120A), and the minimum discharge voltage of the battery is in the range of (40-47v).



Battery settings for Pakistan



.

Battery Settings	Battery Settings	Battery Settings
Ister: Type Solar Cyclone Volta VISIR Solar Cyclone I Volta VISIR Charge Source PV Only PV Then Utility PV + Utility Confirm	Battery Type Solas Cyclene Volta USER SACM FLD TBL Charpe Source No Max Charge Current 120.0 A Image Source Image Source	Battery Type Solax Cyclone Volta USER A GM FLD TBL Charge Source PV Yonly PV Hon Utility P V + Utility PV + Utility Max Charge Current 1200 A A Max Discharge Current 1200 A I200 A I200 A I200 A I200 A
Battery Settings Battery Type Volta USER GAM FLD TBL Charge Source PV Then Utility PV Then Utility PV - Utility T200 A V Max Disclarge Current T200 A V		

Battery settings for other countries



When "USER" is selected, there will be an interface for further settings:



Grid export

Here users can choose between feeding excess PV power into the grid or limiting it. Selecting "No Export" disallows feeding power into the grid, while selecting "Export" allows for it and enables users to set the percentage of power to be fed in as needed. Setting "Max utility charge current" means setting the current that can be taken from the power grid when the battery is charged.



About

Here you can see some basic information of the inverter and battery.

2023/02/03 10:10:00	Inverter Information	About
	Work Mode Smart Load	MDSP Version: 007.05 MDSP BootVer: 001.00
OW STR 1200W	Grid Export Advanced Settings	SMCU Version: 001.00 SMCU BootVer: 003.01 ARM Version: 007.50
	Battery Settings Errors	ARM BootVer: 001.01 Machine SN: HL400670004000
1000W 2200W	Abouts E Country	Wi-Fi SN SXTDCH000L


Smart load

The generator port has three options:


- a. None: No device is connected to the generator port;
- b. Load: The generator port is connected to a load;

Settings options:

- » Smart Load Battery Off Voltage: When the voltage is below the minimum value, the battery will no longer supply power to the smart load;
- » Smart Load Battery On Voltage: When the voltage returns to normal, the battery will supply power to the smart load again.)
- c. Generator: The generator port is connected to the generator.



Advanced settings



The "Basic" and "Advanced" buttons will appear if a password with advanced permission from the installer is used. The initial password for entering the basic settings is 0000, and the initial password for entering the advanced settings is 2014.

All "Basic", "Advanced", and "Super" buttons will appear if a password with factory permission is used. Please contact your installer or factory for factory password.



Basic settings

Basic settings include user-level functional settings such as date time, communication, language, DI/DO functionality and other configuration options.

Setting		Basic Setting	1/2		Basic Setting	2/2
Basic		Language English Communication			Reset Password Meter/CT Install State	Reset
Advanced	-	RS485 Addr 1 RS485 Baud 4800		-	DI Function Set	Disable
		Date Time			DO Function Set CT Sensitivity	Disable Level 1
		2000 / 01 / 01 / 00 : 00 Mute			Battery Sleep LCD Steady Bright	Enable

Advanced settings

Advanced setting is generally customization and resetting for installers and focus on threshold values, including settings for grid protection, factory reset, clearing history record and other configuration options.

Setting	Advan	ced Setting	1/3	Advanced Settin	ig 2/3
Basic Basic Advanced	Grid Protection Safety UECC PV Connection Export Control Meter Direction Q-Power Control Mode Set PF Set	MULTI O Positive		Factory Reset S Reset Meter/CT S Reset Comm Module S	e e e e
	Advan EPS Settings Min Discharge Recover Disch Power Limit Parallel Status Parallel Number	arge SOC 100 100 Sing	3/3		

» Grid protection

		Grid Protecti	on	1/4	Grid Protection	2/4
		Voltage Protection Vol Protect Max1(V) 225.0 Vo Vol Protect Max2(V) 223.0 Vo			Voltage Protection Vol Protect Time Max1 (S) 10.0 Vol Protect Time Max2 (S) 10.0 Vol Protect Time Max3 (S) 10.0	
Advanced Setting 1 Grid Protection E Safety IECol727 PV Connection MULTI Export Control 0	/3	Reconnect Vol Min (V)	ol Protect Min3 (V 220.5) 215.5) 230.0	215.0	Vol Protect Time Min1 (S) 10.0 Vol Protect Time Min2 (S) 10.0 Vol Protect Time Min3 (S) 10.0 Vol Recover Time (10s) 12 Start Delay Time (S) 10	
Meter Direction Positive		Grid Protecti	on	3/4	Grid Protection	4/4
Q-Power Control Enable Mode Set PF Mode PF Set 0		Frequency Protection Freq Protect Max1 (Hz) Freq Protect Max2 (Hz) Freq Protect Max3 (Hz) Freq Protect Min1 (Hz) Freq Protect Min2 (Hz) Freq Protect Min3 (Hz) Freq Reconnect Max (Hz) Freq Reconnect Min (Hz)	50.50 50.50 50.50 49.50 49.50 50.50 50.50 49.50		Frequency Protection Freq Protect Time Max (S) 10.0 Freq Protect Time Max (S) 10.0 Freq Protect Time Max (S) 10.0 Freq Protect Time Mina (S) 9.0 Freq Protect Time Mina (S) 9.0 Freq Protect Time Mina (S) 9.0 Freq Protect Time Mina (S) 9.0	

» Check Parameter

Advanced Sett	ting	2/3		Check I	Parameters
Check Parameter Swore	অ			AI_En ExFanCheck En	Enable
Clear History Record	Set		-	EXFanCheck_En	Enable
Factory Reset	Set				
Reset Meter/CT	Set				
Reset Comm Module	Set				
Reset Energy Record	Set				

» New Password




Errors

Here you can view the current faults and the historical faults. There are a total of five pages with a total of 20 records.

Inverter Information	Current Errors		Error History	1/5
Work Mode Smart Load	ISO_FAIL Error History NO_METER		01. 2023/06/26 12:56:12 NO_METER	
Grid Export Advanced Settings	▶	\rightarrow	02. 2023/06/26 12:55:03 ISO_FAIL	
Battery Settings Errors			03. 2023/05/27 16:2729 SELF_CHECK_FAULT	
Abouts Country			04. 2000/00/00 00:00:00 None	

Country

Here you can select the country. Please note that only when "Pakistan" is selected here will Pakistan's 4 modes be displayed in "Work Mode" and the "Basic Settings" interface will be different accordingly.



11 Operation on SolaX App and Web

11.1 Introduction of SolaXCloud

SolaxCloud is an intelligent management platform for home energy, which integrates energy efficiency monitoring, device management, data security communication and other integrated capabilities. While managing your home energy device, it helps you optimize the efficiency of electricity consumption, improve the revenue of power generation, and meet the unknown energy challenges.

11.2 Operation Guide on SolaXCloud App


11.2.1 Downloading and installing App

Select and scan the QR code below to download SolaxCloud App. You can also find the QR codes at the top left of the login page of www.solaxcloud.com or on the user manual of Pocket module. In addition, you can search with the key word "SolaxCloud" in Apple Store or Google Play to download it.



App Store

Google play



Please check the online App guide, Wifi connection guide or Setup tutorial video on the SolaXCloud App for relevant operation.



Figure 11-2 App guide on SolaXCloud

NOTICE!

• The screenshots in this chapter correspond to the SolaX Cloud App V4.2.8.

11.3 Operation Guide on SolaXCloud Web

Open a browser and enter www.solaxcloud.com to complete registration, login, add site and other related operations according to the guidelines of user guide.

🕩 Demo English 🥾
Solax
Forgot password?
1
te a new account
Terms of Use User Guide

Figure 11-3 User guide on Web

12 Troubleshooting and Maintenance

12.1 Troubleshooting

This section contains information and procedures for resolving possible problems with the inverter, and provides the troubleshooting tips to identify and solve most problems that may occur. Please check the warning or fault information on the system control panel or on the App and read the suggested solutions below when error occurs. Contact SolaX Customer Service for further assistance. Please be prepared to describe the details of your system installation and provide the model and serial number of the inverter.

Error Type	Fault	Descriptions and Diagnosis
INSTALL	ISO_FAIL	Insulation impedance detection failed.Check whether the wire insulation is intact.
INSTALL	NO_PWR_ METER	Electricity meter has no power. Check the status of the meter.
INSTALL	REMOTE_TURN_ OFF	Remote shutdown Restart the inverter.
INSTALL	FREQ_CFG_UN- MATCH	Frequency configuration mismatchCheck whether the frequency is within the correct range.
INSTALL	ARC_FAIL	Arc faultWait for a while to see if it returns to normal.
INSTALL	EPS_OVER- LOAD_105PER	1.05 times overloadTurn off high-power load.
INSTALL	EPS_OVER- LOAD_125PER	1.25 times overloadTurn off high-power load.
INSTALL	EPS_OVER- LOAD_150PER	1.5 times overloadTurn off high-power load.
INSTALL	EPS_OVERLOAD_ LOCK	Overload self-locking Turn off high-power load, PV, battery and power grid, and restart inverter.
INSTALL	PV_CONN_CFG_ ERROR	PV connection configuration error. • Turn off PV, battery and power grid, restart inverter, and confirm whether PV connection is correct.
INSTALL	STARTUP_CON- DITION_FAILL	Startup state failed.Wait for a while to see if it returns to normal.
INSTALL	BUCKBST_CFG_ MODE_ERR	BUCKBST configuration mode error.Check whether the configuration mode of BUCKBST is correct.
PV	PV_01_REVERSE	 PV1 reverse connection Turn off PV, battery and power grid, restart inverter, and check the connection status of positive and negative poles of PV1.
PV	PV_02_REVERSE	 PV2 reverse connection Turn off PV, battery and power grid, restart inverter, and check the connection status of positive and negative poles of PV2.
PV	PV_01_VOLT_ HIGH	PV1 Voltage is too highCheck the output voltage of PV1.

Error Type	Fault	Descriptions and Diagnosis
PV	PV_02_VOLT_ HIGH	PV2 Voltage is too high Check the output voltage of PV2
BAT	BAT_TYPR_CFG_ ERR	Battery type configuration error • Turn off PV, battery and power grid, restart inverter, and confirm whether the battery type is correct.
BAT	BATT_VOLT_ HIGH	Battery voltage is too highCheck whether the battery output voltage is within the normal range.
BAT	BAT_BMS_CELL_ FAULT	BMS battery failurePlease contact the battery supplier.
BAT	BAT_BMS_ COMM_FAULT	BMS communication failureCheck whether the communication between battery and inverteis normal.
BAT	BAT_SOC_LOW	Low battery SOC Please charge the battery in time.
BAT	BAT_CURR_HIGH	High battery current The load is too high, please reduce it appropriately.
GRID	GRID_LOSS	Power grid lossCheck whether the battery input voltage is within the normal working range.
GRID	GRID_OVP1	The grid voltage exceeds the allowable value 1Check whether the grid voltage is within the normal working range.
GRID	GRID_OVP2	The grid voltage exceeds the allowable value 2Check whether the grid voltage is within the normal working range.
GRID	GRID_UVP1	The grid voltage is lower than the allowable value 1.Check whether the grid voltage is within the normal working range.
GRID	GRID_UVP2	The grid voltage is lower than the allowable value 2.Check whether the grid voltage is within the normal working range.
GRID	GRID_OFP1	Power grid frequency exceeds the allowable value 1.Check whether the grid frequency is within the normal working range.
GRID	GRID_OFP2	Power grid frequency exceeds the allowable value 2 Check whether the grid frequency is within the normal working range.
GRID	GRID_UFP1	The power grid frequency is lower than the allowable value 1.Check whether the grid frequency is within the normal working range.
GRID	GRID_UFP2	The power grid frequency is lower than the allowable value 2. • Check whether the grid frequency is within the normal working range.
INV	BST01_SW_OCP	BST1 software overcurrent Wait for a while to see if it returns to normal.
INV	BST02_SW_OCP	BST2 software overcurrent Wait for a while to see if it returns to normal.
INV	BST01_HW_OCP	BST1 hardware overcurrent Wait for a while to see if it returns to normal.

Error Type	Fault	Descriptions and Diagnosis
INV	BST02_HW_OCP	BST2 hardware overcurrentWait for a while to see if it returns to normal.
INV	BST_OVER_PWR	BST overpower • Wait for a while to see if it returns to normal.
INV	BUCKBST_HW_ OCP	BuckBst hardware overcurrentWait for a while to see if it returns to normal.
INV	BUCKBST_SW_ OCP	BuckBst software overcurrentWait for a while to see if it returns to normal.
INV	BUCKBST_SW_ OVP	BuckBst software overvoltageWait for a while to see if it returns to normal.
INV	BUCKBST_SW_ UVP	BuckBst software undervoltageWait for a while to see if it returns to normal.
INV	LLC_HW_OCP	Llc hardware overcurrentWait for a while to see if it returns to normal.
INV	LLC_START_FAIL	Llc startup failed. • Wait for a while to see if it returns to normal.
INV	BUCKBST_ START_FAIL	BuckBst startup failed. • Wait for a while to see if it returns to normal.
INV	DCBUS_INIT_ CHK_FAIL	DCBUS initialization detection failed. • Turn off PV, battery and power grid, and restart inverter.
INV	DCBUS_HW_OVP	DCBUS hardware overvoltageWait for a while to see if it returns to normal.
INV	DCBUS_SW_OVP	DCBUS software overvoltageWait for a while to see if it returns to normal.
INV	DCBUS_SW_UVP	DCBUS software overvoltageWait for a while to see if it returns to normal.
INV	DCBUS_SHORT	DCBUS short circuit Turn off PV, battery and power grid, and restart inverter.
INV	DCBUS_INV_SS_ FAIL	DCBUS inverter soft start failed.Wait for a while to see if it returns to normal.
INV	DCBUS_BST_SS_ FAIL	DCBUS BST soft start failed. • Wait for a while to see if it returns to normal.
INV	DCBUS_BUCKBST _SS_FAIL	DCBUS BUCKBST soft start failed.Wait for a while to see if it returns to normal.
INV	INV_PLL_FAIL	Inverter phase-locked failureWait for a while to see if it returns to normal.

Troubleshooting and Maintenance

Error Type	Fault	Descriptions and Diagnosis
INV	INV_RLY_FLT	Inverter relay faultWait for a while to see if it returns to normal.
INV	INV_RLY_ON_ FAIL	Pull-in fault of inverter relayWait for a while to see if it returns to normal.
INV	INV_EPS_RLY_ FAULT	EPS end relay failureWait for a while to see if it returns to normal.
INV	INV_SS_ACVOLT_ FAIL	Soft start AC voltage failed.Wait for a while to see if it returns to normal.
INV	INV_SW_OCP	Inverter software overcurrentWait for a while to see if it returns to normal.
INV	INV_HW_WAVE_ OCP	Inverter hardware half-wave overcurrentWait for a while to see if it returns to normal.
INV	INV_HW_OCP	Inverter hardware overcurrentWait for a while to see if it returns to normal.
INV	INV_GFCI_CT_ FAIL	CT fault Wait for a while to see if it returns to normal. Check whether CT works properly.
INV	INV_GFCI_PROT	GFCI fault • Wait for a while to see if it returns to normal.
INV	INV_FREQT_OCP	 Inverter frequent overcurrent alarm Wait for a while to see if it returns to normal. Check whether the inverter current works in the normal range.
INV	INV_SW_OVP	Inverter software overvoltagePlease shut down and restart.
VER	TYPE_MODEL_ ERR	Model configuration error • Turn off PV, battery and power grid, and restart inverter. Check whether the inverter model is configured correctly.
BMS	BMS_CELL_ OVER_FAULT	Overvoltage fault of cell. Wait for fault recovery, restart the battery and contact after-sales personnel.
BMS	BMS_CELL_LOW_ FAULT	Undervoltage fault of cell. Recharge the battery
BMS	BMS_CELL_DIFF_ FAULT	Excessive voltage difference fault of cell.Ensure that the battery works in the normal voltage range.
BMS	BMS_HVB_OVER_ FAULT	Overvoltage fault of total voltage.Wait for fault recovery, restart the battery and contact after-sales personnel.
BMS	BMS_HVB_LOW_ FAULT	Undervoltage fault of total voltage. Recharge the battery.
BMS	BMS_TEMP_ OVER_FAULT	High temperature fault.Stop using the battery and wait for the temperature to recover.

Error Type	Fault	Descriptions and Diagnosis
BMS	BMS_SELF_ CHECK_FAULT	Self-test fault.Check the battery failure and contact the after-sales personnel.
BMS	BMS_POS_RLY_ ADH_FAULT	Main positive relay sticking fault.Please contact the after-sales personnel.
BMS	BMS_POS_RLY_ OPEN_FAULT	Main positive relay open circuit fault.Please contact the after-sales personnel.
BMS	BMS_NEG_RLY_ ADH_FAULT	Main negative relay sticking fault. • Please contact the after-sales personnel.
BMS	BMS_NEG_RLY_ OPEN_FAULT	Main negative relay open circuit fault. Please contact the after-sales personnel.
BMS	BMS_PRECHG_ FAIL_FAULT	Pre-charge failure fault.Reset the battery. If this fault is reported many times, please contact after-sales personnel.
BMS	BMS_CELL_SAM- PLE_FAULT	Cell sampling fault. • Please contact the after-sales personnel
BMS	BMS_TEMP_ SAMPLE_FAULT	Temperature sampling fault. • Please contact the after-sales personnel.
BMS	BMS_SYS_FAULT	System fault. • Please contact the after-sales personnel.
BMS	BMS_DSG_ OVER_FAULT	Over-discharge current fault. • Stop using the battery and wait for it to recover or restart the battery. If this fault is reported many times, please contact the after-sales personnel
BMS	BMS_CHG_ OVER_FAULT	Over-charge current fault. Ensure that the battery works in the normal voltage range.
BMS	BMS_AFE_COM_ FAULT	AFE communication fault. • Please contact the after-sales personnel.
BMS	BMS_INV_COM_ FAULT	External network communication fault. • Check the communication line between the battery and the inverter. If this fault still occurs after reinserting the line, please contact the after-sales personnel.
BMS	BMS_MID_COM_ FAULT	Intermediate network communication fault. • Check the communication line between the batteries. If this fau still occurs after reinserting the line, please contact the after-sales personnel.
BMS	BMS_VOLT_SEN- SOR_FAULT	Voltage sensor fault.Please contact the after-sales personnel.
BMS	BMS_ID_REPET_ FAULT	 ID duplication fault. Check if the system connections are correct and follow the initi installation steps to perform the startup operation again.
BMS	BMS_TEMP_ LOW_FAULT	Low temperature fault.Wait for fault recovery, restart the battery and contact after-sale personnel.
BMS	BMS_CURR_SEN- SOR_FAULT	Current sensor fault. Please contact the after-sales personnel.

Error Type	Fault	Descriptions and Diagnosis
BMS	BMS_LINE_FAULT	 Power line open circuit fault. Check whether the power line is connected properly and restart the battery.
BMS	BMS_FLASH_ FAULT	Flash fault.Please contact the after-sales personnel.
BMS	BMS_AFE_PRO- TECT_FAULT	AFE self-protection fault.Please contact the after-sales personnel.
BMS	BMS_CHG_REQ_ FAULT	Charging request fault. Check if the inverter is correctly supplying power to the battery.
BMS	BMS_INS_FAULT	Insulation fault. Please contact the after-sales personnel.
INV	BAT_VOLT_OUT- RANGE	Battery voltage overrun Ensure that the battery works in the normal voltage range.
INV	PV_VOLT_OUT- RANGE	Battery voltage overrun Ensure that PV works in the normal voltage range.
INV	BAT_SOC_LOW_ ON_GRID	Low soc of grid-connected battery Stop discharging and start charging.
INV	BAT_SOC_LOW_ OFF_GRID	Low soc of off-grid battery Stop discharging and start charging.
INV	INV_PWR_DRT	Inverter power deratingEnsure that the inverter power is within the normal range.
INV	BAT_CHRG_ PWR_DRT	Battery charging power derating Ensure that the battery charging power is within the normal range
INV	BAT_DISCHRG_ PWR_DRT	Battery discharge power derating Ensure that the battery discharge power is within the normal range.
INV	BAT_FLOATING_ CHRG	Battery floating charge • Check battery voltage.
INV	BAT_REPLENISH_ CHRG	Battery recharge Check the battery voltage and replenish the power in time.
INV	BAT_PWR_IN_ CFG_MODE	Battery power configuration mode Make sure that the battery works correctly.
INV	BST_IN_CVS_ MODE	BST constant voltage source mode. • BST operates in constant voltage source mode.
INV	PV_PWR_DRT_ INV_PWR_LMT	Inverter power limit • Ensure that the inverter output power is within the normal range
INV	PV_PWR_DRT_ ZERO_EXPORT	Anti-reflux. • Ensure that it is in an anti-reflux state.
INV	PV_PWR_DRT_ CHRG_PWR_LMT	Charging power limit. • Ensure that the charging power is within the normal range.

Error Type	Fault	Descriptions and Diagnosis
INV	PV_PWR_DRT_ CURR_LMT	Current limitingEnsure that the current works within the normal range.
СОМ	INTER_FAN_FAIL	Internal fan failed.Check whether there is any foreign matter inside the fan.
INSTALL	EXTERN_FAN_ FAIL	External fan failure • Please check if the external fan is damaged or blocked
INSTALL	DSP_UPDATE_ FAIL	DSP upgrade failurePlease contact after-sales for assistance with software up grade.
INSTALL	ARM_UPDATE_ FAIL	ARM upgrade failurePlease contact after-sales for assistance with software upgrade.
INSTALL	SMCU_UPDATE_ FAIL	SMCU upgrade failure Please contact after-sales for assistance with software upgrade.
INSTALL	NO_METER	Meter loss Please check if the meter is connected or if the meter commu- niction line works normally.
INSTALL	NO_CT	CT loss Please check if the CT is connected.
INSTALL	NO_NTC	NTC loss Please check if the NTC is connected correctly.
INSTALL	BMS_LOST	Communication loss between inverter and battery management system equipment.Please check the connection status between the BMS device and the inverter.

Please contact our customer service for further assistance. And please be prepared to describe the details of your system installation and provide the inverter serial number and the registration number.

Please check the following list to ensure that the inverter is in the correct operation state if the information panel does not display the fault light.

- Is the inverter located in a clean, dry, and well-ventilated place?
- Is the DC input circuit breaker open?
- Is the specification and length of the cable adequate?
- Are the input and output connections and wiring in good condition?
- Is the configuration set correctly for your particular installation?

12.2 Maintenance

Regular maintenance is required for the inverter. The table below lists the operational maintenance for expressing the optimum device performance. More frequent maintenance service is needed in the worse work environment. Please make records of the maintenance.

WARNING!

- Only qualified person can perform the maintenance for the inverter.
- Only use the spare parts and accessories approved by SolaX for maintenance.

Maintenance routines

Item	Check notes	Maintenance inverval
Safety check	 Check the items mentioned in section 1 "Safety" The safety check shall be performed by manufacturer's qualified person who has adequate training, knowledge, and practical experience. 	Every 12 months
Indicators	 Check if the indicators of the inverter are in normal state. Check if the display of the inverter (if it has screen) is normal. 	Every 6 months
Fans	 Check if the cooling fans on the bottom of the inverter are covered by dirt or if there is abnormal sound. Clean the cooling fans with a soft dry cloth or brush or replace it if necessary. 	Every 6-12 months
Electrical conenction	 Ensure that all cables are firmly connected. Check the integrity of the cables, ensuring that there are no scratches on the parts touching the metallic surface. Verify that the sealing caps on idle terminals terminals are and not falling off. 	Every 6-12 months
Grounding reliability	• Check whether the ground terminal and ground cable are securely connected. Use Ground Resistance Tester to test the ground resistance from inverter enclosure to PE bar in the power distribution box.	Every 6-12 months
Heat sink	 Check whether the heat sink is covered with foreign objects. 	Every 6-12 months

ltem	Check notes	Maintenance inverval
General status of inverter	 Check if there is any damage on the inverter. Check if there is any abnormal sound when the inverter is running. 	Every 6 months

12.3 Firmware Upgrade

12.3.1 Upgrade preparation

- a. Check the inverter version and prepare a U disk (USB 2.0/3.0) and personal computer before upgrading.
- b. Contact our service support to get the update files ("*.bin" and "*.txt" file), and store the two files in the root path of the U disk. Files: X1HybridLV_3_6kW_lap.txt X1HybridLV_3_6kW_***.bin



- Please make sure that the size of the U disk is smaller than 32GB, and the format is FAT16 or FAT32.
- The bin name listed in the "*.txt" file must be same as the "*.bin" name.

12.3.2 Upgrade steps

- **Step 1:** Plug the U disk into the upgrading port below: If the Wi-Fi dongle is connected to the port, please remove the dongle first.
- **Step 2:** After the U disk is plugged in, the system will start upgrading, and the three indicator lights will flash in turns. (Operating indicator: green; battery indicator: blue; Error indicator: Red). Wait approximately 10-15 seconds.
- **Step 3:** After the LCD screen turns off, the buzzer will make a beep sound, and then the screen and three indicator lights will light up again and flash in turns.
- **Step 4:** If the three indicators light up at the same time, it means that the upgrade has been successful. If only the red light is on, it means that the upgrade has failed. If the upgrade fails, please contact our after-sales support.




Figure 12-4 Plug in the U disk

NOTICE!

- The USB disk can be plugged in when the inverter is in normal status.
- After the upgrade is completed, the current state of the indicator will be maintained for 1 minute, and the inverter will be automatically switched on.

13 Decommissioning

13.1 Power off

- a. Turn off the system by System ON/OFF on LCD screen.
- b. Press the Button on the inverter to shut down the system;




Figure 13-1 Pressing the button

- c. Turn off the AC and EPS breakers between the inverter and the power grid;
- d. Turn off the DC switch on the inverter.




Figure 13-2 Turning off DC switch

WARNING!

- Wait for at least 5 minutes to fully discharge the capacitors inside the inverter system.
- After the inverter powers off, there will still be the remaining electricity and heat which may cause electric shocks and body burns. Please wear personal protective equipment (PPE) and begin servicing the inverter five minutes after power off.

13.2 Disassembling the Inverter

WARNING!

- When disassembling the inverter, strictly follow the steps as below.
- Only use measuring devices with a DC input voltage range of 600 V or higher.

Step 1: Use a current clamp to ensure there is no current present in the PV cables.




Figure 13-3 Measuring the current

Step 2: Use the disassembling tool for PV terminal to disassemble the PV cables. Then remove the PV cables, and slightly pull out the cables.




Figure 13-4 Disassembling the PV cables

- **Step 3:** Remove the lower cover of the inverter, measure whether there is AC voltage. If not, remove the cables from Grid, GEN and EPS port.
- **Step 4:** Remove the Communication cable.
- **Step 5:** Remove the Meter/CT cable.
- Step 6: Remove the PE cable.
- Step 7: Remove the Dongle.

- Step 8: Close the lower cover of the inverter.
- **Step 9:** Unscrew the screws of fastening the wall mounting bracket and remove the wall mounting bracket.

Step 10: Remove the inverter.

13.3 Packing the Inverter

- Load the inverter into the original packing material if possible.
- If the original packing material is not available, use the packing material which meets the following requirements:
 - » Suitable for the weight of product
 - » Easy to carry
 - » Be capable of being closed completely




Figure 13-5 Packing the inverter

13.4 Disposing of the Inverter

Please dispose of the inverters or accessories in accordance with the electronic waste disposal regulations applicable at the installation site.

14 Technical Data

14.1 DC Input

Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
Max. PV array power [Wp]	4500	5500	6000	6900	7500	9000
Max. PV input voltage [V]	550					
Start output voltage[V]	110					
Nominal input voltage [V]	360					
MPPT voltage range[V]	80 ~ 520					
No. of MPPT/Strings per MPPT			2(1	./1)		
Max. input current[A]			16	/16		
Max. short circuit current[A]	20/20					
MPPT Voltage Range[V] (Full Load)	115~440	140~440	150~440	175~440	190~440	230~440

14.2 AC Input&Output

Model	X1-HYB-	X1-HYB-	X1-HYB-	X1-HYB-	X1-HYB-	X1-HYB-
Model	3.0-LV	3.7-LV	4.0-LV	4.6-LV	5.0-LV	6.0-LV
Nominal AC Output Current[A]	13	16	17.4	20	21.7	26.1
Nominal AC output power[W]	3000	3680	4000	4600	5000	6000
Max. AC output apparent power[VA]	3300	3680	4400	4600 (Germany 4600)	5000	6000
Max. AC output current [A]	15	16	20	20.9 (Germany 20)	22.7	27.3
Max. AC input apparent power [VA]	6000	7360	8000	9200	9200	9200
Max. AC input current [A]	26.1	32	34.8	40	40	40
Nominal voltage [V], frequency [Hz]			220/230/2	240, 50/60	^	
Displacement power factor		C).8 leading <i>·</i>	~ 0.8 laggin	g	
THDi (rated power) [%]	<3					
AC Connection	L/N/PE					
DC Disconnection Switch			Opti	onal		

14.3 EPS Output

Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
Nominal output power [W]	3000	3680	4000	4600	5000	6000
Peak apparent power[VA] ¹	2 times the rated power, 10s					
Nominal Output Current[A]	13	16	17.4	20	21.7	26.1

Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
Nominal voltage [V], frequency [Hz]	lz] 230, 50/60					
Switch Time[ms]	<10					

14.4 Battery Data

Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
Battery type			Lithium/l	ead-Acid		
Battery voltage range [V]	40~60					
Nominal Battery Voltage[V]	48					
Max. Charging Voltage[V]	<=60 (Adjustable)					
Max. Charging/Discharging Current[A]		75			120	
Charging Strategy for Li-Ion Battery	Self-adaption to BMS					
Charging Strategy for Lead-Acid Battery	/ 3 stages curve					
Temperature Sensor	Optional					

14.5 System Data

Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
MPPT Efficiency	>99.9%					
Max. efficiency [%]	97.6					
Euro. efficiency [%]	97.0					
Battery charge/discharge effciency [%] ²	² 96.0/95.0					

14.6 Protection Device

Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
Anti-Islanding Protection	Yes					
PV String Input Reverse Polarity Protection	Yes					
Insulation Resistor Detection	Yes					
Residual Current Monitoring Unit	Yes					
Output Over Current Protection	Yes					
Output Short Protection	Yes					
Output Over Voltage Protection	Yes					
Surge Protection	AC Type III/DC Type III					
Battery Terminal Temp Protection	Yes					

14.7 Power Consumption & Environment Limit

Model	X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
Self Consumption(night) [W]	Standby < 40, Shutdown < 10					
Degree of protection	IP65					
Operating temperature range[°C]	-25 ~ +60 (derating above +45)					
Relative humidity [%]	0 ~ 100 (condensing)					
Max. operation altitude [m]	<3000					
Storage Temperature[℃]	-25 ~ +70					
Noise Emission(typical)[dB]	<39 <50					

14.8 Protection Device

X1-HYB- 3.0-LV	X1-HYB- 3.7-LV	X1-HYB- 4.0-LV	X1-HYB- 4.6-LV	X1-HYB- 5.0-LV	X1-HYB- 6.0-LV
397x490x201					
16.5				17.5	
Natural				Smart cooling	
Transformerless for PV Side/HF for battery Side					
LED+LCD					
CAN, RS485, CT, Meter, WiFi, LAN, 4G (Optional), USB , NTC, wifi+lan, wifi+4G					
	3.0-LV	3.0-LV 3.7-LV 16 Nai Transform	3.0-LV 3.7-LV 4.0-LV 397x49 16.5 Natural Transformerless for PV LED- CAN, RS485, CT, Meter, WiFi, LAN,	3.0-LV 3.7-LV 4.0-LV 4.6-LV 397x490x201 16.5 Natural Transformerless for PV Side/HF for b LED+LCD CAN, RS485, CT, Meter, WiFi, LAN, 4G (Optional)	3.0-LV 3.7-LV 4.0-LV 4.6-LV 5.0-LV 397x490x201 16.5 17 Natural Smart of Smart of LED+LCD CAN, RS485, CT, Meter, WiFi, LAN, 4G (Optional), USB , NTC,

NOTICE!

• The specific gross weight is subject to the actual situation of the whole machine, which may be a little different due to the influence of the external environment.

Contact Information

UNITED KINGDOM

Unit C-D Riversdale House, Riversdale Road, Atherstone, CV9 1FA

- +44 (0) 2476 586 998
- service.uk@solaxpower.com

TURKEY

KIZILSARAY MAH. 76 SK. LATIF AYKUT İSMERKEZİ ALTI NO:16 B- İC KAPI NO: - MURATPAŞA / ANTALYA

+90 549 841 45 97

invertersatis@altaytech.com.tr

USA 📃

3780 Kilroy Airport Way, Suite 200, Long Beach, CA, US 90806

- +1 (408) 690 9464
- info@solaxpower.com

POLAND

WARSAW AL. JANA P. II 27. POST

- +48 662 430 292
- service.pl@solaxpower.com

ITALY

+39 011 19800998 support@solaxpower.it



PAKISTAN

+92 341 2687002 service.pk@solaxpower.com owais@solaxpower.com

🐱 AUSTRALIA

- 21 Nicholas Dr, Dandenong South VIC 3175
- +61 1300 476 529
- service@solaxpower.com

GERMANY

- Am Tullnaupark 8, 90402 Nürnberg, Germany
- +49 (0) 6142 4091 664
- service.eu@solaxpower.com
- service.dach@solaxpower.com

NETHERLANDS

\mathbf{Q}	Twekkeler-Es 15 7547 ST Enschede
2	

- +31 (0) 8527 37932
- service.eu@solaxpower.com
- service.bnl@solaxpower.com



SPAIN

+34 9373 79607 🖌 tecnico@solaxpower.com



BRAZIL

+55 (34) 9667 0319 🖌 info@solaxpower.com

SOUTH AFRICA



+27 83 565 5865 service.za@solaxpower.com 📉 rajen@solaxpower.com



SolaX Power Network Technology (Zhejiang) Co., Ltd.

Add.: No. 288, Shizhu Road, Tonglu Economic Development Zone, Tonglu City, Zhejiang Province, 310000 P. R. CHINA

Tel.: +86 (0) 571-5626 0011

E-mail: info@solaxpower.com



Copyright © SolaX Power Technology (Zhejiang) Co., Ltd. All rights reserved.